		HEM		
		FOLD 90°		
HEM HEM	FOLD 90°	 Glue sparingly in centre only Trim sheet to dotted line CAREFULLY Centrepunch and drill all holes with 1/8" double-ended drill bit CAREFULLY cut out edges CAREFULLY Fold hems CAREFULLY Fold long edges (not too far!) Spread ends of long hems slightly CAREFULLY Fold ends, slipping tabs into long hems 	FOLD 90°	HEM
		Design Updated 16-11-01 G Wellwood		
		FOLD 90°		
		HEM		